

Miro LC Touchscreen - Introduction to the interface

- Screen is used both as a viewfinder and for touchscreen controls
- Most of the images shown are with the screen flipped around and folded back into the side of the camera

Square button: Click once to bring up touch screen menu
Click again to exit the menu, but keep on-screen display on.
Exiting the menu is an electronic reset of the touchscreen
Reset takes about 5 seconds. Double-clicking the square button also resets the screen.




Circle button: Click to turn on and off all screen displays. This is useful to see an unobstructed viewfinder display.



Note: tapping the center of the screen will also bring up menu icons


The display will flip vertically when positioned upside down (such as mounted against side of camera, facing outward)



Tap the menu icon as indicated to bring up the main capture and setting control interface



Scroll up and down for desired setting
Tap once to select parameter to change



Miro LC Touchscreen - Full Menu

Scroll up & down, tap to select

Speed	100 f/s
Exp. Time	9ms 324°
Resolution	1280x800
Post Trigger	10 fr 0%
Auto Exposure	Off
Exposure Index	4000
Video Format	NTSC
Color Bars	Off
Prod. Area	0x0
White Balance	5191K
Color Comp.	+0.51
Master Gamma	2.222
IBAT Enable	Off
IBAT Area	1x1
IBAT Position	-1,-1
IBAT Speed	0 fr
IBAT Sensitivity	Custom
RAM Partitions	1
At End of Recording	Do Nothing
Language	English
Advanced Settings	On
Auto Exp. Comp.	0.000
Shutter	Enabled
EDR	0µs 0%
Frame Burst	Off
Burst Period	305.9µs
Auto Black Ref.	Off
Save Region Start	First Frame
Save Region End	Last Frame
Frame Sync	Internal
Trigger Polarity	Falling Edge
Trigger Filter	32µs
Frame Delay	0ns
Aux Signal	Strobe
Ready Deasserts	After Trigger
Saturation	1.000
Master Black	0.000
Gain	1.000 1.000 1.000
Pedestal	0.000 0.000 0.000
Gamma	2.222 2.222 2.222
Matrix	Off
Tone	Off
PA Offset	0,0



Select a menu item by tapping once. On the right, + and - symbols will appear when applicable, and a keyboard symbol can also be selected for data entry



The keyboard/data entry menu allows you to enter any available value, then tap the 'return' key to accept




The Exposure time menu allows the camera's exposure to be entered in microseconds, milliseconds or degrees



The Post Trigger can be entered in frame count or percentage. The value represents the amount of frames past the trigger point to be stored in RAM



The camera's white balance can be set with the AWB on the upper right or manually by adjusting the color temperature and color compensation



The IBAT parameters control the camera's 'Image Based Auto Trigger' functions. These settings fine-tune the accuracy of the trigger, based on your event



Several languages are available for the menu display: English, German, Spanish, French, Japanese, Chinese and more



End of recording, or 'automatic actions' can be set: Play, Save, Play & Restart, Save & Restart, Play Save & Restart



With Advanced Settings Off, the menu ends here, and all advanced parameters go to the camera's default



With Advanced Settings On, the menu expands and the camera's full functionality can be accessed


Miro LC Touchscreen - Top menu controls, capture menu and on-screen display




Factory & User Settings menu: Load the factory settings, access 3 factory-saved presets, or store up to 6 of your own presets



When saving a user-setup, enter a name and tap the 'return' button to save it. Any of the 3 factory-saved presets can be modified or overwritten




When loading any of the user settings or factory defaults, you must tap to confirm or cancel




Cine Management: View and select cine files stored in RAM, save and/or delete to re-arm the camera



Tap CF in Cine Management menu to bring up list of files stored on CineFlash drive. Delete individual takes or tap 'XCF' to format (secure erase) the drive.



Main menu display



Camera info displays model, serial #, memory size, firmware level, and current temperature readings




AWB automatically adjusts the camera's white balance. Place a white or neutral object in the center square and tap once. White subject must not be fully saturated



Menu categories are used to jump to certain places in the camera's main menu list.

Status indicator: Capture mode, Cine Stored, Playback, Live

Trigger point, frame count, record time



CineFlash status and free space indicator

Trigger. Trigger is also available from red button on front of the camera body, or via capture port.

Voltage & Battery life indicator (counts down)


Frame rate

Exposure time & Shutter angle

Resolution



Play Cine files in RAM. Tap forward or reverse multiple times to speed up playback. Tap in and out points and save to CineFlash. Apply a long press over the in & out markers to reset



Front camera buttons

1) Auto-set (top right)

Tap to scroll through video tools functions: Zoom (1:1), Threshold and Live mode
Long press (3 seconds) will perform an internal CSR (current session reference)

2) Trigger button (lower right)

Tap once to trigger the camera
Long press (5 seconds) will delete the last RAM Cine file and re-arm the camera